

PRESSALIT.

Product	MATRIX CURVE ergonomic wash basin with overflow	
Item number	R2050000	
	VVS:636859100	
	NRF:6191675	
	EAN:5708590207957	
	HMI: 42540	
	NBS:N13:30,335	
Colour	White 190	
Product description	MATRIX is a series of wash basins, most of them are designed by Pressalit. MATRIX SMALL and CURVE wash basins fit onto PLUS, SELECT and VALUE basin brackets, whereas MATRIX MEDIUM, ANGLE, ANGLE DEEP and SQUA are tailor made to fit specific brackets.	
	MATRIX CURVE ergonomic wash basin, 600 x 490 x 190 mm, with tap hole Ø36 mm and overflow. Supplied with drain fitting. The concave front edge stabilises standing as well as seated users. The rounded edges are also comfortable to hold and rest against. The flat bottom leaves room for the legs underneath. Material: Ceramic. Suitable for wash basin brackets from the Pressalit PLUS, SELECT and VALUE	
	ranges.	
Product capacity	200 kg.	
Materials	Ceramic	
Ergonomy	The concave front edge stabilises a standing as well as a seated user. The rounded shapes are nice to grip and lean against. The design of the corners leaves space and supports the elbows in the basin and the flat bottom leaves space for the legs of a seated user.	
Warranty	Pressalit makes a commitment to remedy material and manufacturing defects for a period of five years from the invoicing date.	



PRESSALIT.

Product Item number	MATRIX CURVE ergonomic wash basin with overflow R2050000
Cleaning	Wash basin For cleaning the wash basin, use hot water and a mild soapy cleaning agent. Make sure that the product is wiped down with a soft rag wrung out in clear water immediately after cleaning. For disinfecting the wash basin, the following agents can be used: Sodium hydroxide 5% Acetic acid solution 10% Ethanol solution 70% Sodium hypochlorite 5%, active chlorine Sodium chloride 170g/l, diluted to 50%. Make sure that the product is wiped down with a soft rag wrung out in clear water immediately after disinfection. NB! Do not use abrasive cleaning agents, as this will cause damage to the surface of the wash basin.
Declaration of conformity	Declaration of Performance Compliance criteria according to EN 14688:2015. 4.1 Load resistance: Passed. 4.6 Cleanability: Passed. 4.7 Protection against overflowing: CL 25. Durability: Passed



PRESSALIT®


Product
Item number

MATRIX CURVE ergonomic wash basin with overflow

R2050000

Installation in different wall types


Concrete >B25 V8602 - Mounting kit, 2 coach screws Ø10 x 100 - plugs SX12. To be ordered separately	
Solid Brick >= Mz12 V8602 - Mounting kit, 2 coach screws Ø10 x 100 - plugs SX12. To be ordered separately	
Solid Sand Lime Brick >= HIz12 V8602 - Mounting kit, 2 coach screws Ø10 x 100 - plugs SX12. To be ordered separately	
Aerated Concrete P4 V8652 - Mounting kit, 2 coach screws Ø10 x 100 - plugs GB14.	



Drywall (2 x 12,5 mm) water-resistant, re-enforced with wood

V8602 - Mounting kit, 2 countersunk screws \emptyset 10 x 80, plugs SX12. NB! Plugs are not needed. To be ordered separately.

To be ordered separately.





PRESSALIT®

Product Item number	MATRIX CURVE ergonomic wash basin with overflow R2050000	
	Drywall (2 x 12,5 mm) water-resistant, re-enforced with 22 mm plywood Mounting in this wall type is not recommended - risk of fatal injury to persons and walls.	<u>^!</u>
	Drywall (2 x 12,5 mm) water-resistant, re-enforced with steel plates (2 mm) Mounting in this wall type is not recommended - risk of fatal injury to persons and walls.	<u>^!</u>
	Drywall (2 x 12,5 mm) water-resistant Mounting in this wall type is not recommended - risk of fatal injury to persons and walls.	<u>^</u>

It is the responsibility of the installer to ensure that suitable wall fasteners are used.

pressalit.com