

# PRESSALIT.

Product	Changing table, 800 x 1800 mm, electrically height adjustable, with sanitary appliances and standard mixer tap		
Item number	R8735000		
	VVS:777630330	1800	
	NRF:7501987		
	EAN:5708590333786 HMI: 105715		
Colour	White	max 1000 min 650	
Product description	Pressalit offers a wide range of daycare changing tables, both free-standing and wall-hung, in several sizes and models. The wall-hung tables are also available in versions where the worktop folds away, which are suitable for rooms with limited space. Of particular use to daycare facilities and kindergartens are the low start wall-hung changing tables, which can be lowered to a height that allows children to climb onto the worktop themselves.  All types of daycare changing tables are available in versions with sanitary appliances and a choice of taps, with or without pull-out shower heads.		
	With electric motor and transform wired hand control.		
Adjustability	Height adjustable		
Adjustment height	350 mm		
Product capacity	Max load: 150 kg.		
Speed upwards	Speed up mm: 14 mm/s Speed down mm: 14 mm/s		



### PRESSALIT®

ustable, with sanitary	
R8735000	
Lifting unit and baskets: Powder-laquered steel. Worktop: Melamine. Waste pipe: Polyurethane, PVC and steel. The flexible waste pipe is very resistant to both chemical and physical influences. It is flame retardant and withstands temperatures from -30°C to +110°C.	
The smooth height adjustment ensures that it is always possible to set the table at an ergonomically correct height.	
Easy-to-clean surfaces ensure optimum hygiene. Underglued sink and tap.	
230	
2 x LA31 Deskline (Linak), 1500N, IPX1	
CBD6 (Linak), IP20	
cturing defects for a	



## PRESSALIT.®

Product	Changing table, 800 x 1800 mm, electrically height adjustable, with sanitary appliances and standard mixer tap  R8735000	
ltem number		
Cleaning	Daycare changing tables The product is to be cleaned with hot water or a mild soapy cleaning agent. Do not use chlorine based, corrosive or abrasive cleaners as it may result in the surface being damaged.  The following cleaning agents have been tested by Pressalit and may be used, as long as they are diluted according to the instructions on the container.  DISINFECTANTS: Clinimax Difficil-S Erisan OXY+ Sprit (husholdningssprit) Suma Bac D10 Virkon Rodalon Desinfektionsspray Lysoformin Spezial CaviCide Sufanios Premium Tvättsprit 70%  NON-DISINFECTANTS: Suma Star free D1 Taski 100 Taski 200 Millizid Citro  The product must be wiped down with a soft rag wrung out in clear water immediate after cleaning, as some materials may otherwise be discolored and stained, and the	



#### PRESSALIT®

**Product** 

Item number

Changing table, 800 x 1800 mm, electrically height adjustable, with sanitary appliances and standard mixer tap

R8735000

#### Installation in different wall types

Concrete >B25  V8608 - Mounting kit, 6 coach screws Ø10 x 70 - plugs SX12.  To be ordered separately.	
Solid Brick >= Mz12  V8608 - Mounting kit, 6 coach screws Ø10 x 70 - plugs SX12.  To be ordered separately.	
Solid Sand Lime Brick >= HIz12  V8608 - Mounting kit, 6 coach screws Ø10 x 70 - plugs SX12.  To be ordered separately.	
Aerated Concrete P4  V8658 - Mounting kit, 6 coach screws Ø10 x 70 - plugs GB14.  To be ordered separately.	
Drywall (2 x 12,5 mm) water-resistant, re-enforced with wood  V8608 - Mounting kit, 6 coach screws Ø10 x 70 - plugs  SX12. NB! Plugs are not needed.  To be ordered separately.	



### PRESSALIT®

Product Item number	Changing table, 800 x 1800 mm, electrically height adjustable, with sanital appliances and standard mixer tap  R8735000	
	Drywall (2 x 12,5 mm) water-resistant, re-enforced with 22 mm plywood  Wall fasteners (6 pcs) must be bought separately, for drywall it is possible to use e.g. fischer KD8 toggles or similar.	
	Drywall (2 x 12,5 mm) water-resistant, re-enforced with steel plates (2 mm)  Wall fasteners (6 pcs) must be bought separately, for drywall it is possible to use e.g. fischer KD8 toggles or similar.	
	Drywall (2 x 12,5 mm) water-resistant  Mounting in this wall type is not recommended - risk of fatal injury to persons and walls.	

pressalit.com

Pressalit A/S
Pressalitvej 1
DK-8680 Ry
Tel.: +45 8788 8788
Fax: +45 8788 8789
E-mail: pressalit@pressalit.com