



Product Item number	Lift for countertop, manually height adjustable RK1182
Product description	<p>EAN:5708590293813 HMI: 61271</p> <p>The name INDIVO relates to the individual configuration of the products.</p> <p>Manual lift for freestanding countertop. For countertops from 78.8" - 94.5". Height adjustable 11.8". Including 2 telescopic legs, brackets, longitudinal and cross braces and crank handle. Pressalit recommends overhang and 15.8" at either end of countertop to allow for ease of approach in wheel-chair. Please state desired length when ordering.</p>
Adjustability Product capacity	<p>Height adjustable</p> <p>Maximum load (evenly distributed): 220 lbs including countertop.</p>
Materials Ergonomy	<p>Material: Telescopic leg: Aluminium, ABS plastic Cross braces: Aluminium Brackets: Steel Crank handle: Steel Surface treatment: Brackets: Powder lacquered (grey RAL 9006)</p> <p>A manual, freestanding Indivo solution is the budget choice when you need a work or dining table which can be adapted to the given user or situation. A freestanding countertop can also be used in rooms in which the walls are not strong enough to support the wall-mounted models.</p>



Product Item number	Lift for countertop, manually height adjustable RK1182
Features	<p>Lift heights are adjusted in height using a crank handle. Manual lifts may be used with countertops with or without an edge. The crank handle socket can be positioned anywhere along the long sides of the countertop. The design of the legs and feet make the table stable and secure, and ensure the lift causes minimal inconvenience to wheelchair users. The design of the lift makes it possible to use the countertop from all sides. Height adjustable over a range of 11.8". Available for countertops of any length between 55.1" and 11.8".</p>
Warranty Cleaning	<p>Pressalit makes a commitment to remedy material and manufacturing defects for a period of three years from the invoicing date.</p> <p>This product should be cleaned with hot water or a mild cleaning solution. Do not use chlorine based, corrosive or abrasive cleaners as it may result in the surface being damaged.</p> <p>The following cleaning agents have been tested by Pressalit and may be used, as long as they are diluted according to the instructions on the container.</p> <p>DISINFECTANTS: Clinimax Difficil-S Erisan OXY+ Sprit (husholdningsprit) Suma Bac D10 Virkon Rodalon Desinfektionsspray Lysoformin Spezial CaviCide Sufanios Premium Tvättsprit 70%</p> <p>NON-DISINFECTANTS: Suma Star free D1 Taski 100 Taski 200 Milizid Citro</p> <p>The product must be wiped down with a soft rag wrung out in clear water immediately after cleaning, as some materials may otherwise be discolored and stained, and the surface coating may deteriorate.</p> <p>DECALCIFICATION OF ALUMINUM PARTS: Pressalit recommends that water deposits (Calcium, lime etc.) be removed from wall tracks and other aluminum parts using a solution of three parts of 30% acetic acid to seven parts tap water. When the aluminum parts have been washed down with this solution, the parts should be wiped over with a damp cloth wrung out in plain water.</p>



PRESSALIT®

Product	Lift for countertop, manually height adjustable
Item number	RK1182

pressalit.com

Pressalit A/S
Pressalitvej 1
DK-8680 Ry
Tel.: +45 8788 8788
Fax: +45 8788 8789
E-mail: pressalit@pressalit.com

PRESSALIT®