

PRESSALIT.

Product Item number	Touchfree faucet with temperature control RT632
	EAN: 5708590377094 $ \begin{array}{cccccccccccccccccccccccccccccccccc$
Product description	Touchfree bathroom faucet with temperature control lever that can be set to dispensivate at the desired temperature. The touch-free faucet is activated by an infrared sensor that responds to hand motion turning on and off automatically, and provides a solution for safer and more hygienic hand-washing. Equiped with a made-to-last surface and for saving water, and still guarantee optimal water flow. Easy installation and a battery life of 7 years (150 uses per day). Touchfree faucet with temperature control, infrared sensor, adjustable control lever and long battery life. ADA compliant. Complies with ASME A112.18.1/CSA B125.1 We recommend T4679 plumbing kit with 0.4"compatible adaptor.
Features	Infrared electronic activation Thermal disinfection 7 preset programs Auto-flush and Cleaning mode ON/OFF Battery powered (includes CR-P2 lithium battery) Battery life: 7 years (150 uses per day) Multi-stage battery life status display Stainless steel braided flexible supply with 3 /8" compression fitting Includes strainer and check valve on the inlet 0.5gpm (1.9Lpm) multi-laminar spray 0.1 Gallon per washing cycle (CALGreen compliant) Maximum running time: 12 seconds per cycle
Warranty	Pressalit makes a commitment to remedy material and manufacturing defects for a period of five years from the invoicing date.



PRESSALIT®

Product Item number	Touchfree faucet with temperature control RT632
Cleaning	Recommended cleaning of the chrome surfaces of the fitting. The fitting must be cleaned with neutral or mild alkaline (pH 6-9) liquid cleaning agents, and the detergent manufacturer's instructions for use and dosing must alway be followed. Wet a sponge or a soft cloth with detergent solution and clean all surfaces of the faucet. Then rinse the faucet with plenty of clean, mildly warm water, and finally dry the faucet. IMPORTANT! Do not use a spray bottle to apply detergent directly to the faucet. Organic solvents, corrosives or abrasives must not be used.

pressalit.com

Pressalit A/S
Pressalitvej 1
DK-8680 Ry
Tel.: +45 8788 8788
Fax: +45 8788 8789
E-mail: pressalit@pressalit.com